


Circularity of Critical Raw Materials in PEM Water Electrolyzers

L. Sandig-Predzymirska, A. Charitos



5th of June 2024



DANISH
TECHNOLOGICAL
INSTITUTE



Sustainable
INNOVATIONS



TECHNISCHE UNIVERSITÄT
BERGAKADEMIE FREIBERG
The University of Resources. Since 1765.



PRÜF**REX**


ACCUREC
RECYCLING GMBH



Hycenta
HYDROGEN CENTER AUSTRIA


Fraunhofer
ICT

u^b
UNIVERSITÄT
DUISBURG
ESSEN




OBJECTIVES:

1. Develop and manufacture highly active sustainable **oxygen evolution catalysts for PEM** (Proton Exchange Electrolyzer) that will **reduce or eliminate the use of CRMs** (Critical Raw Materials), thus decreasing CO_2 emissions and reducing cost
2. Establish a **recycling scheme** for proton exchange membrane electrolyzers catalysts, electrodes and overall systems, by **implementing the recovered elements in the new developed catalysts**, thus reaching a full circular economy



Automated sorting of MEA




Automatic sorting process:


- Capture image in the waste stream
- Detect circle in the image
- Detect color in the image
- Move the robotic arm to pick the detected MEAs (Membrane Electrode Assembly)
- Recycle other parts to recover Ti




Pyrometallurgical recovery of CRMs



- CaCO₃ as trapping solid for F-containing gases
- FactSage® calculation indicated Ru losses above 1100 °C
- Not all F-containing gases can be captured by solid, the off-gas cleaning system is required



Metallic bottom-phase




Inorganic top-phase

Material pre-treatment

Test MEA


2cm×2cm

- Pt/C
- IrRu/ATO
- Nafion® membrane
- C substrate
- Ti-plated substrate



Pre-treatment

IPA:H₂O / US



MEA


D ~ 9cm

- Pt/C
- IrRu/ATO
- Nafion® membrane
- C substrate



Pre-treatment


IPA:H₂O / US / 40 °C




Solid residue

Pt	10.89±0.79%
Ir	6.44±0.19%
Ru	1.50±0.15%
Sb	0.94±0.08%
Sn	14.85.0±0.24%

SEM-images (x100)





MEA anode side - untreated





MEA anode side – IPA+H₂O

Leaching





Optimized parameters:

- HCl conc. – 8 M
- H₂O₂ conc. – 10 vol%
- Additive – AlCl₃
- Temperature – 75 °C
- S/L ratio – 4 g/L
- Stirring rate – 500 rpm



- Easy leaching of PtRu/C catalyst in HCl-based solution
- High resistance of IrRu/ATO catalyst in acidic media
- An additional step (fusion) is required to improve the dissolution of IrRu/ATO


Ru volatilization



➤ Soft oxidation conditions (from 55 °C) by using persulfate salt

➤ High Ru recovery (up to 100 %) from the catalyst solution

➤ Sulfonic and carboxylic acids work very well for RuO_4 capture → method patented




*Feed material: IrRu/ATO, T = 60 °C

L. Sandig-Predzymirska, T.V. Barreiros, A. Thiere, A. Weigelt, M. Stelter, A. Charitos:
 "Verfahren zur Rückgewinnung von Ruthenium aus einem Ruthenium-haltigen Material"
 DE102022111440


Lewatit MP TP260

(Amino methyl phosphonic acid)




Lewatit MP TP214

(Thiourea)




Lewatit TP207

(Iminodiacetic acid)





Lewatit MP62

(Tertiary amine)




Amberlite IRC748

(Iminodiacetic acid)





- Sb separation from other metals is possible with Lewatit MP62
- Search for selective eluents was performed








Ion exchange

Ion exchange scheme




- Lewatit MP62 adsorption step: Pt (96%) was removed and some Sn&Ir (61% and 48%), no Sb was adsorbed
- Washing step: 3h with water (~20-25% Sn, <0.5% PGMs)
- NaOH removed all metal ions – at 0.1M (100% Ir, 95% Pt, and 77% Sn)
→ As the result above 95% (washing+elution steps) of metals was recovered

Solvent extraction





Diluent	Dielectric constant
Kerosene	1.8
Diesel	2.1
Toluene	2.38
Octanol	10.3

➤ Pt/Ir separation is possible with Cyanex923 in Diesel



Solvent extraction



Stripping agents

1. Organic compounds:

ascorbic acid, oxalic acid, thiourea

2. Sodium salts:

NaNO_3 , NaCl , Na_2SO_4 , Na_2CO_3 , NaOH

3. Mineral acids:

HNO_3 , H_2SO_4 , HCl



Optimized extraction parameters:

- Cyanex 923 conc. – 1 - 50 vol%
- Diluent – Diesel, Toluene, Benzene, Octanol
- HCl conc. – 2 - 10 M
- Aq.:Org. – 3:1 - 1:10
- Mixing time – 5 - 120 min
- Stirring rate – 200 - 700 rpm
- PGM conc. – 50 - 1000 mg/L
- Temperature – 25 - 50 °C

➤ At optimized parameters:

$\text{Pt} = 99.2 \pm 0.3\%$

$\text{Ir} = 8.0 \pm 1.3\%$




Number of cycles	1	2	3	4
Extraction efficiency of Cyanex 923 Pt (%)	99.24	99.22	99.35	99.07



This Project has received funding from the European Union's Horizon 2020 Research and Innovation Programme under Grant Agreement N. 861960

U. Otgonbayar, L. Sandig-Prezdymska, A. Thiere, A. Charitos, Solvent extraction of Pt, Ru, and Ir using Cyanex 923 in chloride media to develop a recycling route for spent polymer electrolyte membrane (PEM) electrolyzers, Hydrometallurgy, 2024, 226, 106303, <https://doi.org/10.1016/j.hydromet.2024.106303>

Oxidation and precipitation




- No co-precipitation of Sn and Sb
- ➔ Up to 94.4% Pt was precipitated with 5M NH₄Cl

- Ru recovery from trapping solution:

- Oxidize Ru³⁺ to Ru⁴⁺



- Precipitate Ru⁴⁺ at HCl conc. > 4M




- ➔ At optimized conditions up to 94.8% of Ru was precipitated

- Ir³⁺ oxidation to Ir⁴⁺ takes place with H₂O₂
- Ir⁴⁺ precipitates at HCl conc. > 1M
- ➔ At optimized conditions up to 97.6% of Ir was precipitated



This Project has received funding from the European Union's Horizon 2020 Research and Innovation Programme under Grant Agreement N. 861960


SEM-images (x5.000)




$(\text{NH}_4)_2\text{PtCl}_6$



$(\text{NH}_4)_2\text{RuCl}_6$



$(\text{NH}_4)_2\text{IrCl}_6$




Material	Efficiency, %	Metal content, %			
		Calculated	Commercial	Recycled	
			Given by the producer	Analysed by ICP-OES	Analysed by ICP-OES
$(\text{NH}_4)_2\text{PtCl}_6$	94%	43.9	43.4	47.9	42.3
$(\text{NH}_4)_2\text{RuCl}_6$	95%	28.9	28.4	30.9	30.6
$(\text{NH}_4)_2\text{IrCl}_6$	96%	43.6	43.0	45.9	45.8

- The slightly higher deviation for Pt salt (ICP-OES) → NH_4Cl residues (2-8% (XRD) $T_{\text{dec}}=340^\circ\text{C}$) → Pt salt can not be as easily washed after filtration as Ru or Ir salts with ethanol



This Project has received funding from the European Union's Horizon 2020 Research and Innovation Programme under Grant Agreement N. 861960



Thanks a lot for your attention!



Questions?

My contact:



Dr. Lesia Sandig-Predzymirska
Group leader „EoL Recycling“

TU Bergakademie Freiberg
Institut für Nichteisen-Metallurgie und Reinstoffe
ZeHS, Winklerstraße 5, EG.113
09599 Freiberg

Tel.: +49373139-2027

E-Mail: Lesia.Sandig-Predzymirska@inemet.tu-freiberg.de

WWW.RECYCALYSE.EU



RECYCALYSE



RECYCALYSE

info@recycalyse.eu